

Circuit Breaker trips	Condition: Circuit breaker trips during the firing. The breaker or fuse will shut off the power to the kiln immediately or at some time during the firing. Check electrical installation requirements for your kiln.	8.2
		General
		Cbtrips.vsd

